



Tips on Lightning Clear

Do not wait too long between Coats!

Waiting as long as 10-15 min could result in cracking

Apply 1st full wet coat

Apply 2nd coat within 1-2 min

If sanding and buffing apply a third coat for long term durability

If melting in the edge make sure to have your blending gun close by and spray the edge of clear immediately after the last coat.

Reparability time

Allow the Clear to dry for 1 ½ hrs. before making repairs.

Robert Coker

Technical Representative

Vogel Automotive Coatings

Cell # 606-304-1238

