

Tips on spraying

AG Specialty Industrial Enamel

Note:

Hardener (# 7019) improves the Chemical resistance, Gloss, Durability and dry time.

Mix ratio:

8 parts color to 1 part #7019 Hardener to 3 parts Synthetic En. Reducer

After adding Hardener allow a 15 min. “sweat in time” before adding Solvent

Synthetic Enamel Reducer is recommended for best results!

Viscosity at 8:1:3 is 20 sec. 1.4 tip will give best results!

Apply 2-3 coats allowing 10-15 min flash time between coats

Adhesion to bare steel and aluminum is excellent!

Do not Clearcoat over the AG Specialty Industrial Enamel!

Robert Coker

Technical Representative

Vogel Automotive Coatings

Cell # 606-304-1238

