



## **Tips on spraying Axis Flat Clear CC 900**

**Shake for 15 minutes. To avoid settling, keep the mix stirred and shake the gun regularly.**

**Mix 4:1 and do not add any Solvent to the mix!**

**Spray 2 med wet even coats overlapping 75%**

**A 1.4 or larger tip is recommended**

**Do not sand and buff!**

*Robert Coker  
Technical Representative  
Vogel Automotive Coatings  
Cell # 606-304-1238*