



Tips on using Axis Epoxy Primer

It can be used “under” for adhesion to various substrates

It will adhere directly to Factory E-coat without scuffing

It can be used “over” as a Sealer

Available in Gray, Black and White

It is can be sanded (will actually powder)

This Epoxy will level very smooth and clean (no grit)

It can be used in hot weather without dusting by adding Super Flow Solvent. Mix 1 part Epoxy to 1 part Activator to ½ part Super Flow Solvent.

Use Mod. SuperFlow @ 75° or Hot Weather SuperFlow @ 85°

Topcoat after 30 min up 24 hr dry (without sanding)

For maximum adhesion, after 24 hr dry, scuff with a red pad and apply 1 coat of Epoxy at the 1: 1: ½ ratio.

Robert Coker - Technical Representative

Vogel Automotive Coatings - Cell # 606-304-1238

