



Tips on AXIS FLAT BLACK

Mix 4:1: ½

Use a 1.4 Tip

Apply 2 wet coats overlap 75%

Can be applied wet on wet

(2-5 min flash between coats)

Do not sand and buff!

Robert Coker

Technical Representative

Vogel Automotive Coatings

Cell # 606-304-1238